810f02a7

(Continued) CONNECTOR GROUND SPLICE LOCATION G104 ABSOLUTE PRESSURE SENSOR MANIFOLD Ω ENGINE COOLANT TEMPERATURE SENSOR ENGINE OIL PRESSURE SWITCH PLUG NO. 7 S105 COIL ON COIL ON PLUG NO. 5 FUEL INJECTOR NO. 5 **-S107** FUEL INJECTOR NO. 7 **S124** FUEL INJECTOR NO. 3 **S121** IDLE AIR CONTROL MOTOR COIL ON PLUG NO. 3 CAPACITOR NO. 2 FUEL INJECTOR NO. 1 THROTTLE POSITION SENSOR **S158** COIL ON PLUG No. 1 INTAKE AIR TEMPERATURE SENSOR A/C COMPRESSOR CLUTCH

Fig. 18 ENGINE LEFT FRONT 4.7 L